WCS-6006 wooden cabinet 5.1 system

Disclaimer

- We spared no efforts to make sure that the information in this manual is correct and complete. However no liability is accepted for any errors or omissions. Gembird Electronics reserves the right to change the specifications of the hardware and software described in this manual without prior notice.
- No part of this manual may be reproduced, transmitted or translated in any language in any form, by any means, without the prior written permission of Gembird Electronics Ltd.
- Gembird Electronics makes no warranties for damages resulting from corrupted or lost data due to a mistaken operation or malfunction of the product, the software, personal computers or peripheral devices.

Gembird® is a registered trademark of GMB Tech (Holland) bv.
Other names or products not mentioned above may be registered trademarks or trademarks of their respective owners.

Copyright © 2007 Gembird Electronics Ltd. All rights reserved.

Introduction

Thank you for buying WCS-6006 wooden cabinet 5.1 system! This manual will help you install and use it properly.

Features and specifications

- Power ON/OFF and Master Volume controls
- Subwoofer: 3.5", 5W
- Front: 3", 2W*2
- Rear: 3", 2W*2
- Center: 3", 2W
- Frequency Response: 60Hz-18KHz
- S/N Ratio: >50dB
- Separation: >55dB
- Input Sensitivity: 300mV
- Input Impedance: >12 Kohm

Speakers installation diagram



Output installation





5.1 input



FRONT REAR SUB\CENT

(2.1 input)




DVD/MP3 Player


1
FRONT
R
L
FRONT
REAR
SUB
CEN
OUTPUT
REAR
SUB/CEN


2
3
4
VOLUME
BASS

Instructions

- The loudspeakers should be placed on a flat and solid surface
- Press the keys gently and turn the knob evenly
- Do not touch the metallic portion of the power supply connector
- Do not pull the electric cord to unplug the connectors without holding the sockets
- Do not open the housing to avoid electric shock or other accidents
- Turn the volume knob to the minimum position before turning the power on. Turn the volume to your comfortable range after power is on
- Keep good ventilation, far from heat source, and avoid direct sunlight
- unplug, the loudspeakers are not in use for a long time
- Be careful and do not spill water any other liquid, or put miscellaneous items inside the housing of the system
- Pay special attention to turn the volume of the sound source to mid-low level to avoid product damages caused by large signal input
- Do not allow the loudspeaker to operate for long hours under maximum volume
- When the master volume knob is adjusted to the two-third position of the of the scale, the best sound effect will be heard.